# 快速接頭

Fitting

## 直接頭



NO	4-M5	4-01	4-02	6-M5	6-01	6-02	6-03	8-01	8-02	8-03	8-04	10-02	10-03	10-04	12-02	12-03	12-04
管徑	4	4	4	6	6	6	6	8	8	8	8	10	10	10	12	12	12
牙口	M5	1/8"	1/4"	M5	1/8"	1/4"	3/8"	1/8"	1/4"	3/8"	1/2"	1/4"	3/8"	1/2"	1/4"	3/8"	1/2"

#### 90°彎接頭



NO	4-M5	4-01	4-02	6-M5	6-01	6-02	6-03	8-01	8-02	8-03	8-04	10-02	10-03	10-04	12-02	12-03	12-04
管徑	4	4	4	6	6	6	6	8	8	8	8	10	10	10	12	12	12
牙口	M5	1/8"	1/4"	M5	1/8"	1/4"	3/8"	1/8"	1/4"	3/8"	1/2"	1/4"	3/8"	1/2"	1/4"	3/8"	1/2"

#### 三通中牙接頭



NO	4 <b>-</b> M5	4-01	4-02	6-M5	6-01	6-02	6-03	8-01	8-02	8-03	8-04	10-02	10-03	10-04	12-02	12-03	12-04
管徑	4	4	4	6	6	6	6	8	8	8	8	10	10	10	12	12	12
牙口	M5	1/8"	1/4"	M5	1/8"	1/4"	3/8"	1/8"	1/4"	3/8"	1/2"	1/4"	3/8"	1/2"	1/4"	3/8"	1/2"

#### 調速接頭



NO	4-M5	4-01	4-02	6-M5	6-01	6-02	6-03	8-01	8-02	8-03	8-04	10-02	10-03	10-04	12-02	12-03	12-04
管徑	4	4	4	6	6	6	6	8	8	8	8	10	10	10	12	12	12
牙口	M5	1/8"	1/4"	M5	1/8"	1/4"	3/8"	1/8"	1/4"	3/8"	1/2"	1/4"	3/8"	1/2"	1/4"	3/8"	1/2"

#### 三通邊牙接頭



NO	4 <b>-</b> M5	4-01	4-02	6-M5	6-01	6-02	6-03	8-01	8-02	8-03	8-04	10-02	10-03	10-04	12-02	12-03	12-04
管徑	4	4	4	6	6	6	6	8	8	8	8	10	10	10	12	12	12
牙口	M5	1/8"	1/4"	M5	1/8"	1/4"	3/8"	1/8"	1/4"	3/8"	1/2"	1/4"	3/8"	1/2"	1/4"	3/8"	1/2"

#### 內牙彎接頭



NO	4-M5	4-01	4-02	6-M5	6-01	6-02	6-03	8-01	8-02	8-03	8-04	10-02	10-03	10-04	12-02	12-03	12-04
管徑	4	4	4	6	6	6	6	8	8	8	8	10	10	10	12	12	12
牙口	M5	1/8"	1/4"	M5	1/8"	1/4"	3/8"	1/8"	1/4"	3/8"	1/2"	1/4"	3/8"	1/2"	1/4"	3/8"	1/2"

#### 內牙直接頭



NO	4-M5	4-01	4-02	6-M5	6-01	6-02	6-03	8-01	8-02	8-03	8-04	10-02	10-03	10-04	12-02	12-03	12-04
管徑	4	4	4	6	6	6	6	8	8	8	8	10	10	10	12	12	12
牙口	M5	1/8"	1/4"	M5	1/8"	1/4"	3/8"	1/8"	1/4"	3/8"	1/2"	1/4"	3/8"	1/2"	1/4"	3/8"	1/2"

#### 內六角彎接頭



NO	4-M5	4-01	4-02	6-M5	6-01	6-02	6-03	8-01	8-02	8-03	8-04	10-02	10-03	10-04	12-02	12-03	12-04
管徑	4	4	4	6	6	6	6	8	8	8	8	10	10	10	12	12	12
牙口	M5	1/8"	1/4"	M5	1/8"	1/4"	3/8"	1/8"	1/4"	3/8"	1/2"	1/4"	3/8"	1/2"	1/4"	3/8"	1/2"

#### 彎接頭(加長)



NO	4 <b>-</b> M5	4-01	4-02	6-M5	6-01	6-02	6-03	8-01	8-02	8-03	8-04	10-02	10-03	10-04	12-02	12-03	12-04
管徑	4	4	4	6	6	6	6	8	8	8	8	10	10	10	12	12	12
牙口	M5	1/8"	1/4"	M5	1/8"	1/4"	3/8"	1/8"	1/4"	3/8"	1/2"	1/4"	3/8"	1/2"	1/4"	3/8"	1/2"

#### 調速接頭-S型



NO	4-M5	4-01	4-02	6-M5	6-01	6-02	6-03	8-01	8-02	8-03	8-04	10-02	10-03	10-04	12-02	12-03	12-04
管徑	4	4	4	6	6	6	6	8	8	8	8	10	10	10	12	12	12
牙口	M5	1/8"	1/4"	M5	1/8"	1/4"	3/8"	1/8"	1/4"	3/8"	1/2"	1/4"	3/8"	1/2"	1/4"	3/8"	1/2"

### 內牙隔板接頭



NO	4-01	4-02	6-01	6-02	6-03	8-01	8-02	8-03	10-02	10-03	10-04	12-02	12-03	12-04		
管徑	4	4	6	6	6	8	8	8	10	10	10	12	12	12		
牙口	1/8″	1/4″	1/8″	1/4″	3/8″	1/8″	1/4″	3/8″	1/4″	3/8″	1/2″	1/4″	3/8″	1/2″		

# Y型中牙異徑接頭 (可彎曲)-NPX



NO	4 <b>-</b> M5	4-01	4-02	6-M5	6-01	6-02	6-03	8-01	8-02	8-03	8-04	10-02	10-03	10-04	12-02	12-03	12-04
管徑	4	4	4	6	6	6	6	8	8	8	8	10	10	10	12	12	12
牙口	M5	1/8"	1/4"	M5	1/8"	1/4"	3/8"	1/8"	1/4"	3/8"	1/2"	1/4"	3/8"	1/2"	1/4"	3/8"	1/2"

#### 雙插彎接頭



NO	4	6	8	10	12
<u> </u>	4	6	8	10	12
管徑					

#### 雙插直接頭



NO	4	6	8	10	12
管徑	4	6	8	10	12
官 1至					

#### 三通接頭



NO	4	6	8	10	12
管徑	4	6	8	10	12
官1空					

#### 雙插隔板接頭



NO	4	6	8	10	12
管徑	4	6	8	10	12
官1至					



NO	6-4	8-6	10-8	12-10		
φ <b>D2</b>	6	8	10	12		
φ <b>D1</b>	4	6	8	10		

#### 三通異徑接頭



	NO	6-4	8-6	10-8	12-10
q	b <b>D2</b>	6	8	10	12
q	∌ <b>D1</b>	4	6	8	10

#### 雙插異徑直接頭



NO	6-4	8-6	10-8	12-10
管徑	6	8	10	12
官工主	4	6	8	10

#### Y型接頭(可彎曲)



NO	4	6	8	10	12	
<u> </u>	4	6	8	10	12	
管徑						

#### U型接頭(雙插)



NO	4	6	8	10	12	
管徑	4	6	8	10	12	
官1至						

Y型異徑接頭(可彎曲)



NO	6-4	8-6	10-8	12-10
φ <b>D2</b>	6	8	10	12
φ <b>D1</b>	4	6	8	10

線圏接線盒

防爆線圈

PU管/NY管 油壓緩衝器

金屬接頭

Brass Push-In Fitting

#### 直接頭



NO	4 <b>-</b> M5	4-01	4-02	6 <b>-</b> M5	6-01	6-02	6-03	8-01	8-02	8-03	8-04	10-02	10-03	10-04	12-02	12-03	12-04
管徑	4	4	4	6	6	6	6	8	8	8	8	10	10	10	12	12	12
牙口	M5	1/8"	1/4"	M5	1/8"	1/4"	3/8"	1/8"	1/4"	3/8"	1/2"	1/4"	3/8"	1/2"	1/4"	3/8"	1/2"

90°彎接頭



NO	4-M5	4-01	4-02	6-M5	6-01	6-02	6-03	8-01	8 <b>-</b> 02	8-03	8-04	10-02	10-03	10-04	12-02	12-03	12-04
管徑	4	4	4	6	6	6	6	8	8	8	8	10	10	10	12	12	12
牙口	M5	1/8"	1/4"	M5	1/8"	1/4"	3/8"	1/8"	1/4"	3/8"	1/2"	1/4"	3/8"	1/2"	1/4"	3/8"	1/2"

三通中牙接頭



NO	4-M5	4-01	4-02	6-M5	6-01	6-02	6-03	8-01	8-02	8-03	8-04	10-02	10-03	10-04	12-02	12-03	12-04
管徑	4	4	4	6	6	6	6	8	8	8	8	10	10	10	12	12	12
牙口	M5	1/8"	1/4"	M5	1/8"	1/4"	3/8"	1/8"	1/4"	3/8"	1/2"	1/4"	3/8"	1/2"	1/4"	3/8"	1/2"

調速接頭



NO	4-M5	4-01	4-02	6-M5	6-01	6-02	6-03	8-01	8-02	8-03	8-04	10-02	10-03	10-04	12-02	12-03	12-04
管徑	4	4	4	6	6	6	6	8	8	8	8	10	10	10	12	12	12
牙口	M5	1/8"	1/4"	M5	1/8"	1/4"	3/8"	1/8"	1/4"	3/8"	1/2"	1/4"	3/8"	1/2"	1/4"	3/8"	1/2"

三通邊牙接頭



NO	6-01	6-02	6-03	8-01	8-02	8-03	8-04	10-02	10-03	10-04	12-02	12-03	12-04		
管徑	6	6	6	8	8	8	8	10	10	10	12	12	12		
牙口	1/8"	1/4"	3/8"	1/8"	1/4"	3/8"	1/2"	1/4"	3/8"	1/2"	1/4"	3/8"	1/2"		

內牙彎接頭



NO	6-01	6-02	6-03	8-01	8-02	8-03	8-04	10-02	10-03	10-04	12-02	12-03	12-04		
管徑	6	6	6	8	8	8	8	10	10	10	12	12	12		
牙口	1/8"	1/4"	3/8"	1/8"	1/4"	3/8"	1/2"	1/4"	3/8"	1/2"	1/4"	3/8"	1/2"		

變徑接頭

#### 三通接頭



NO	4	6	8	10	12
管徑	4	6	8	10	12
'官'1坣					

雙插彎接頭

5 5 5 5 5 5 5						
de a	NO	4	6	8	10	12
	<u> </u>	4	6	8	10	12
C	管徑					

A. Commission	-
×4	
-	DESCRIPTION OF THE PERSON OF T
NPGC	

NO	6-4	8-6	10-8	12-10
管徑	6	8	10	12
官主	4	6	8	

## 雙插直接頭



NO	4	6	8	10	12	
管徑	4	6	8	10	12	
'官' 1空						

#### 內牙直接頭



	NO	4-01	4-02	6-01	6-02	6-03	8-01	8-02	8-03	10-02	10-03	10-04	12-02	12-03	12-04		
	管徑	4	4	6	6	6	8	8	8	10	10	10	12	12	12		
	牙口	1/8"	1/4"	1/8"	1/4"	3/8"	1/8"	1/4"	3/8"	1/4"	3/8"	1/2"	1/4"	3/8"	1/2"		
•		•	•					•	•								



NO	4	6	8	10	12
<u> </u>	4	6	8	10	12
管徑					

# 不鏽鋼接頭

SUS316 Stainless Steel Push-In Fitting

#### 直接頭



NO	4-M5	4-01	4-02	6-M5	6-01	6-02	6-03	8-01	8-02	8-03	8-04	10-02	10-03	10-04	12-02	12-03	12-04
管徑	4	4	4	6	6	6	6	8	8	8	8	10	10	10	12	12	12
牙口	M5	1/8"	1/4"	M5	1/8"	1/4"	3/8"	1/8"	1/4"	3/8"	1/2"	1/4"	3/8"	1/2"	1/4"	3/8"	1/2"

#### 90°彎接頭



NO	4-M5	4-01	4-02	6-M5	6-01	6-02	6-03	8-01	8-02	8-03	8-04	10-02	10-03	10-04	12-02	12-03	12-04
管徑	4	4	4	6	6	6	6	8	8	8	8	10	10	10	12	12	12
牙口	M5	1/8"	1/4"	M5	1/8"	1/4"	3/8"	1/8"	1/4"	3/8"	1/2"	1/4"	3/8"	1/2"	1/4"	3/8"	1/2"

#### 三通中牙接頭



NO	4-M5	4-01	4-02	6-M5	6-01	6-02	6-03	8-01	8-02	8-03	8-04	10-02	10-03	10-04	12-02	12-03	12-04
管徑	4	4	4	6	6	6	6	8	8	8	8	10	10	10	12	12	12
牙口	M5	1/8"	1/4"	M5	1/8"	1/4"	3/8"	1/8"	1/4"	3/8"	1/2"	1/4"	3/8"	1/2"	1/4"	3/8"	1/2"

#### 三通邊牙接頭



NO	4-01	4-02	6-01	6-02	8-01	8-02	10-02	10-03	12-02	12-03	12-04			
管徑	4	4	6	6	8	8	10	10	12	12	12			
牙口	1/8"	1/4"	1/8"	1/4"	1/8"	1/4"	1/4"	3/8"	1/4"	3/8"	1/2"			

#### 內牙直接頭



NO	4-01	4-02	6-01	6-02	6-03	8-01	8-02	8-03	10-02	10-03	10-04	12-02	12-03	12-04		
管徑	4	4	6	6	6	8	8	8	10	10	10	12	12	12		
牙口	1/8"	1/4"	1/8"	1/4"	3/8"	1/8"	1/4"	3/8"	1/4"	3/8"	1/2"	1/4"	3/8"	1/2"		

#### 雙插直接頭



NO	4	6	8	10	12
管徑	4	6	8	10	12
官 1至					

#### 三通接頭



NO	4	6	8	10	12	
管徑	4	6	8	10	12	
官 1王						